



Product Fitting – Under gunwale shelving

Tools

Screwdriver, cordless or manual

Rigid Construction

These shelves are pretty much ready to go. Slot into place and simply use the provided brackets to fix the shelves to the wall. A single bracket is typically sufficient, but we would recommend two if possible.

The best place to put them is under the top at the back, i.e. just below gunwale height. This is the most discrete placement and it also makes them robust and resistant to toppling if pulled on.

Fix the brackets to the underside of a shelf (or shelves) in the position of your choice and then fix into the wall.

Take care that where you are fixing there are no cables or pipes close to the surface.

Flatpack

Flatpack shelves have been pre drilled and preassembled. This means they should slot together easily and can be constructed with either an electric screwdriver (or impact driver) or manual.

All shelves will be labelled with numbers (or numbers and letters if you have ordered multiple shelves for easy identification) and arrows showing which way is up.

The numbered ends go into the corresponding numbered slots. Ensure all arrows are pointing up!

The screw holes are countersunk. For a countersunk finish simply put the screws into the predrilled holes.

If you want to use the screwcaps provided, then put these on the screws first and put screws into each of the holes. Take care not to overtighten and crush the screw cups

No glue is required. You can use a combination of countersunk and screw cup fixings, e.g. countersunk where shelves meet and then screw cups on the end.

You can fill the countersunk screw holes if desired.

Once fully assembled follow “Rigid Construction” fitting directions to fix them off to your wall for safety.